



INSTALLING LATAPOXY® 2000



PROPER PREPARATION

THE critical step when applying any surface.

Goal:

- clean
- dry
- room temperature.

- 1 Remove all loose tile and set new tile OR...
- 2 Cut out grout lines. 1/4" minimum depth.
- 3 Degrease, flush thoroughly.
- 4 Vacuum dry. Ready to grout.



MIXING & INSTALLATION

- 1 Pour Part A-hardener pouch and Part B-resin pouch into empty 5 gal pail.
- 2 Mix thoroughly, use low speed.
- 3 Add filler powder and mix thoroughly using low speed.
- 4 Pour material onto surface and work into grout lines.
- 5 Draw grout float diagonally
- 6 over tile.
- 7 Use warm water and scrubby pad to remove excess.
- 8 Draw clean, damp towel across surface.

COVERAGE CHART				
TILE SIZE	JOINT WIDTH			
	1/16"	1/8"	1/4"	3/8"
4 x 8 x 1/2"	200	100	50	36
4 x 8 x 1 1/2"	70	40	20	15
6 x 6 x 3/8"	300	150	80	50
6 x 6 x 1/3"	220	110	60	40

